


For Use With Modified Roof Systems



1. Roof Membrane

Follow the general recommendations of Flex for membrane treatment at the roof edge. Position modified membrane over over the roof edge and down the outside face as shown.

IMPORTANT! Outside edge of treated wood nailer(s) (minimum 2 x 4) shall be aligned flush with or extend slightly past outermost edge of wall. Flexlock FLE HG Roof Edge is for use as a perimeter securement on roof designs where the product is not installed in a waterline. If the product will be in a waterline or requires drainage over the edge, we would recommend the use of Flexlock FLE Canted Fascia or Flexlock Drip Edge, depending on desired retention of water or drainage.



NOTE: Flex may require a sacrificial flashing strip. (Refer to drawing 2A & 2B).
Please check with Flex prior to installation.



2. Roof Edge

Install sacrificial flashing strips according to membrane manufacturers recommendations. Install the largest manageable lengths possible to minimize overlaps under the anchor bar. Following the applicable flashing method (hot mop, cold adhesive, etc.) according to the Flex's recommendations, lay the flashing strip into place extending a minimum 8" onto the roof membrane and down the outside face of wall, 1/2" beyond the wood nailer.



NOTE: In cold weather, the back of flashing strip should be treated appropriately and shorter lengths of flashing strips should be used.

For Use with Built-Up Roof Systems

1. Roof Membrane

Prior to the application of the Flexlock FLE-HG Roof Edge, it is suggested that the contractor follow the common recommended industry practice of installing an envelope over the ends of the base or B.U.R. plies. As always, follow the general recommendations of Flex for membrane treatment at the roof edge.



IMPORTANT! Outside edge of treated wood nailer(s) (minimum 2 x 4) shall be aligned flush with or extend slightly past outermost edge of wall. Flexlock FLE HG Roof Edge is for use as a perimeter securement on roof designs where the product is not installed in a waterline. If the product will be in a waterline or requires drainage over the edge, we would recommend the use of Flexlock FLE Canted Fascia or Flexlock Drip Edge, depending on desired retention of water or drainage.



2. Roof Edge

Cut flashing strip into the longest possible sections manageable to minimize laps at the edge. Starting at outside edge, mop surface of felts out onto the roof membrane with Type III or IV asphalt. Lay the flashing strip into place over the roof edge extending 1/2" below nailer and onto the roof membrane a minimum of 8". The sheet should be worked-in to ensure that it is firmly and uniformly bonded. In cool or cold weather, the back of flashing strip should also be mopped with the hot bitumen, and shorter lengths of flashing strips should be used. Laps in the flashing strip should be a minimum of 3" and well sealed.


NOTE! Flashing strip is material used in construction of traditional flashing systems on built-up roofs. It readily conforms to transitions at the outside edge and wall area. (Follow general recommendations Flex.)



3. Miter & Scupper Anchor Bar (Preparation)

OPTIONAL INSTALL

Lay miters and spillout scuppers on deck with outside face down. Be sure aluminum anchor bar is clean and free of dirt or dust. Refer to Fig. A or B, depending on roofing manufacturer's recommendations. For Fig. A, Apply a 3" wide 1/4" thick band of mastic to the back of the anchor bar as shown. For Fig. B apply a heavy 3/8" bead of non-curing sealant to the back of anchor bar as shown. Application of either type of mastic or sealant is required along the full length of each miter anchor bar.




4. Anchor Bar Splice Plates

Apply mastic or sealant to each splice plate as shown and as described in STEP 3. Ensure the sealant is placed into the grooves along the spacer.

CAUTION! Installers shall wear protective eyewear to prevent injury. Do not over-drive fasteners, as stripping can occur at high driver torque. Recommended driving tool: 600-800 rpm electric drill equipped with depth-sensing nosepiece to prevent over-driving and stripout.

Do not use impact type tool.



5. Miter Bar Installation


Install miters using 2" stainless steel fasteners and driver bit furnished by Flex. Fasten anchor bar corners to nailer with one splice plate under each end of corner.

The anchor bar must insert into the grooves of the splice plate. Next locate and install spillouts and scuppers with mastic or sealant, 2" fasteners and anchor bar splice plates.

DIAGONAL SLOT ANCHOR BAR INSTALLATION


NOTE: IF THE SLOTS ON THE ANCHOR BAR ARE ALL HORIZONTAL, NOT DIAGONAL, FASTEN IN THE CENTER OF THE SLOT

PLACE FASTENER AT TOP
OF SLOT FOR SINGLE
NAILER INSTALLATION




PLACE FASTENER AT TOP
OF SLOT FOR SINGLE
NAILER INSTALLATION

PLACE FASTENER AT BOTTOM
OF SLOT IF 1/2" COVER BOARD
IS USED




PLACE FASTENER AT BOTTOM
OF SLOT IF 1/2" COVER BOARD
IS USED

PLACE FASTENER AT BOTTOM
OF SLOT IF FASTENING INTO
MASONRY



PLACE FASTENER AT BOTTOM
OF SLOT IF FASTENING INTO
MASONRY

PLACE FASTENER AT BOTTOM
OF SLOT IF FASTENING INTO
ELIMINAILER-T



PLACE FASTENER AT BOTTOM
OF SLOT IF FASTENING INTO
ELIMINAILER-T




FLEXLOCK FLE-HG FASCIA

BUILT-UP OR MODIFIED VERSION


INSTALLATION INSTRUCTIONS

IMPORTANT! Be sure to remove protective plastic film prior to installing each fascia section.




6. Anchor Bar Installation

Position 12' anchor bar sections with applied non-curing sealant as shown in step 3, overlapping anchor bar splice plate. Allow $\frac{3}{8}$ " space between anchor bars. Install anchor bar splice plate at other end of bar section. Fasten anchor bar 12" O.C. through slotted holes using provided 2" fasteners. The anchor bars must insert into the grooves of the splice plate. Field cut sections as necessary.




7. Fascia Miter Covers

Install miter covers first. Insert one splice plate under each end of the two piece miter cover. Engage cover with 90° tab onto bottom of anchor bar and rotate miter cover up and over anchor bar miter until engaged along entire length of the anchor bar. Repeat steps to install miter cover without the 90° tab.



8. Fascia Covers

Install 12'-0" fascia cover sections. Allow a $\frac{3}{8}$ " gap between fascia cover sections. Insert one splice plate under far end of each fascia cover section. Install cover by hooking lower edge of cover onto anchor bar and rotating cover up and over anchor bar until engaged along entire length of cover section. Continue to install cover sections in this manner, field cutting where necessary using a fine tooth hacksaw.



Customer Service
Phone: 800-969-0108
Fax: 610-916-9501

DATE: 10/30/19


DRN BY: ZS

CKD BY: JAI

SHT.# 4 OF 5


DWG# 28110-11787

G




1. Roof Membrane

Follow the general recommendations of Flex for membrane treatment at the roof edge. Position modified membrane over the roof edge and down outside face of wall as shown.




2. Scupper Anchor Bar (Preparation)

Lay miters and spillout scuppers on deck with outside face down. Be sure aluminum anchor bar is clean and free of dirt or dust. Apply a 3 1/2" wide 1/4" thick band of mastic to the back of the anchor bar as shown. Application of mastic is required along the full length of each miter anchor bar.



3. Scupper Installation

Install scuppers using 2" stainless steel fasteners. Fasten the scuppers to nailers with one splice plate under each end of scupper anchor bar. Position adjacent 12'-0" sections of anchor bar into the grooves of the splice plate.



4. Flashing Installation

Overlay scupper deck flange with flashing material as specified by Flex.