

FASCIA EXTENDER WITH SPLICE PLATES

IMPORTANT : PRIOR TO INSTALLATION, READ INSTRUCTIONS CAREFULLY.

INSTALLATION INSTRUCTIONS

NOTE : INSTALL MITERS BEFORE FULL LENGTH EXTENDER SECTIONS.

STEP ① POSITION 12'-0" CONTINUOUS CLEAT SECTIONS THEN FASTEN 12" O.C. AS SHOWN WITH APPROPRIATE FASTENERS. LAP CONTINUOUS CLEAT 1" AT JOINTS.

SPLICE PLATE

① MITER

STEP ② INSTALL EXTENDER MITERS FIRST. INSERT ONE SPLICE PLATE UNDER EACH END OF MITER AS SHOWN. FASTEN WITH APPROPRIATE FASTENERS FOR SUBSTRATE.

STEP ③ INSERT ONE SPLICE PLATE UNDER LEFT END OF 12'-0' LONG EXTENDER SECTION AS SHOWN.

STEP ④ INSTALL 12'-0" EXTENDER SECTIONS. EXTENDER SHALL BE INSTALLED FROM RIGHT TO LEFT AS SEEN FROM ROOFTOP. HOOK DRIP EDGE OF EACH EXTENDER SECTION ONTO CONTINUOUS CLEAT. FASTEN WITH APPROPRIATE FASTENERS.

EXTENDER SECTIONS ④

② CONTINUOUS CLEAT

③ SPLICE PLATE

FASTEN EXTENDER AND CONTINUOUS CLEAT WITH APPROPRIATE FASTENERS

⑤ 3/8" (9.53 mm) SPACE AT EACH JOINT

STEP ⑤ CONTINUE BY INSTALLING EXTENDER SECTIONS ALLOWING A 3/8" (9.53 mm) SPACE BETWEEN SECTIONS AS SHOWN. FIELD CUT AS NECESSARY.

CAUTION : REMOVE PROTECTIVE FILM IMMEDIATELY BEFORE INSTALLATION. INSTALLERS SHALL WEAR PROTECTIVE EYEWEAR TO PREVENT INJURY.

TYPICAL INSTALLATION
(Substrate may vary per job conditions.)

