

310 Quadral Dr. Wadsworth, OH 44281 Phone: (800) 356-3521 www.soprema.us

## INSTALLATION INSTRUCTION FOR SOPRA-TITE GOLD COPING

### **APPROVALS\***

ANSI/SPRI/FM 4435/ES-1






\*MAXIMUM TESTED DIMENSIONS: OUTSIDE FACE: 12" | WALL WIDTH: 32" | INSIDE FACE: 4"

DATE: 02/19/25 | DRN BY: MLM | CKD BY: MM | DWG #: 33111-44336 | REV. B

## **TABLE OF CONTENTS**

Overview of Coping Versions	Page 3
Substrate and Fastener Information	Page 4
Anchor Clip Spacing	Page 4
Standard Installation Steps(Including Standard Accessories)	Page 5-7
Radius Coping Installation Steps	Page 8

COPING VERSIONS





800-356-3521 www.soprema.us

310 Quadral Dr. Wadsworth, OH 44281 f: 330-334-6257 DATE: 02/19/25 DRN BY: MLM


CKD BY: MM

SHT.#<u>3</u> OF <u>8</u>

FASTENERS AND ANCHOR CLIP INFORMATION

#### **COPING SUBSTRATE AND FASTENERS**

THIS COPING CAN BE INSTALLED ON THE FOLLOWING SUBSTRATE USING THE FASTENERS PROVIDED BY THE MANUFACTURER . TYPICAL INSTALLATION ON WOOD SUBSTRATE. (TAPERED VERSION SHOWN)



SUBSTRATE	TOP FASTENERS	FACE FASTENERS
WOOD	#10 X 1-1/2" STAINLESS STEEL SCREW	#14 X 1-1/2" PROFILER
MASONRY	1/4" X 1-1/4" TAPCON	#14 X 1-1/2" PROFILER
METAL	#12-14 X 1" TEK3	#14 X 1-1/2" PROFILER


NOTE: ALTERNATIVE OR UNIVERSAL FASTENERS MAY BE PROVIDED AS A SUBSTITUTE FOR THE FASTENERS LISTED BASED ON AVAILABILITY. ANY SUBSTITUTE FASTENER PROVIDED WILL BE OF EQUAL OR GREATER EQUIVALENCY.

#### COPING ANCHOR CLIPS AND SPACING

ANCHOR CLIP SPACING IS DETERMINED BY THE MANUFACTURER BASED ON WALL SIZE.

## ANCHOR CLIP DETAIL FOR WALLS GREATER THAN 14"

NOTE: ALL RADIUS COPING WILL HAVE DOUBLE SPRING ANCHOR CLIPS



#### ANCHOR CLIP SPACING FOR STRAIGHT LENGTHS

WALL SIZE	ANCHOR CLIP SPACING
0" THRU 16"	4' - 0" O.C.
16 - 1/16" THRU 24"	3' - 0" O.C.
24-1/16" THRU 39 7/8"	2' - 0" O.C.

#### ANCHOR CLIP AND SPLICE PLATE INFORMATION FOR RADIUS COPING

WALL WIDTH	SPLICE PLATE WIDTH	ANCHOR CLIP WIDTH	ANCHOR CLIP SPACING



800-356-3521 www.soprema.us

310 Quadral Dr. Wadsworth, OH 44281 f: 330-334-6257 DATE: 02/19/25 DRN BY: MLM

CKD BY: MM

SHT.#\_4\_ OF \_8

DWG# 33111-44336


|B|

INSTALLATION INSTRUCTIONS


IMPORTANT: PRIOR TO INSTALLATION, READ INSTRUCTIONS CAREFULLY.

NOTE: POSITION ROOF MEMBRANE ON TOP OF THE WALL COVERING THE TREATED WOOD NAILER(S) OR SUBSTRATE COMPLETELY. ALLOW 1/2" MINIMUM EXCESS MEMBRANE BEYOND NAILER WHERE APPLICABLE. NRCA REQUIREMENT.


**CAUTION: INSTALL MITERS FIRST!** 




# STEP 2 - MITER SPLICE PLATES & ANCHOR CLIPS REMOVE RELEASE PAPER FROM SPLICE PLATE SEALANT STRIPS. POSITION THE SPLICE PLATE IN THE CENTER OF THE ANCHOR CLIP. INSTALL THE SPLICE PLATE AND ANCHOR CLIP ASSEMBLIES HALFWAY INTO EACH END OF THE CORNER MITER AS SHOWN.




LOCATE AND FASTEN GALVANIZED ANCHOR CLIPS TO THE WALL WITH PROVIDED FASTENERS FOR SUBSTRATE, AS SHOWN IN DETAIL A. FOR FASTENER DETAIL SEE PAGE 4.




STEP 1 - CORNER SUPPORT CLIPS
LOCATE AND FASTEN THRU GALVANIZED CORNER SUPPORT CLIP
TO THE WALL AS SHOWN. FOR FASTENER DETAIL SEE PAGE 4.



NOTE: REMOVE PROTECTIVE PLASTIC FILM IMMEDIATELY.



REMOVE RELEASE PAPER FROM THE TOP OF THE FACTORY APPLIED SEALANT STRIPS. PLACE THE SPLICE PLATE ONTO THE SECOND ANCHOR CLIP AS SHOWN.



NOTE: REMOVE PROTECTIVE PLASTIC FILM IMMEDIATELY.



800-356-3521 www.soprema.us

310 Quadral Dr. Wadsworth, OH 44281 f: 330-334-6257 DATE: 02/19/25 DRN BY: MLM CKD BY: MM

SHT.#\_5\_OF\_8

INSTALLATION INSTRUCTIONS

NON-CURING SEALANT


NON-CURING SEALANT

(BY OTHERS).

STEP 7 - ENDWALL FLASHING COPING VERSIONS STEP 7 - 8 NOTE: WITH THIS ENDWALL FLASHING THERE ARE TWO ANCHOR CLIPS AND ONE WITH A SPLICE PLATE.

HOOK OUTSIDE FACE OF ENDCAP OVER THE ANCHOR CLIPS AND ROTATE INTO PLACE. ENGAGE REAR LEG ONTO ANCHOR CLIPS BY PRESSING DOWNWARD UNTIL SNAP LOCK OCCURS.


NOTE: REMOVE PROTECTIVE PLASTIC FILM IMMEDIATELY.



#### STEP 8 - ENDWALL FLASHING


FASTEN TO WALL USING APPROPIATE FASTENERS (BY OTHERS) AS SHOWN. APPLY NON-CURING SEALANT (BY OTHERS) TO CAULK CUP AT TOP OF FLANGE.

NOTE: REMOVE PROTECTIVE PLASTIC FILM IMMEDIATELY.



STEP 9 - ENDWALL FLASHING SPLICE PLATE VERSION STEPS 9 - 10 NOTE: WITH THE ENDWALL FLASH SPLICE PLATE VERSION THERE IS ONE ANCHOR CLIP.

PLACE ENDWALL FLASHING ON TOP OF ANCHOR CLIP. REMOVE RELEASE PAPER FROM FACTORY APPLIED SPLICE PLATE SEALANT STRIPS. FASTEN TO WALL USING APPROPRIATE FASTENERS (BY OTHERS) AS SHOWN. APPLY NON-CURING SEALANT (BY OTHERS) TO CAULK CUP AT TOP OF FLANGE.



#### STEP 10 - COPING

HOOK OUTSIDE FACE OF COPING OVER THE ANCHOR CLIP / ENDWALL FLASHING AND ROTATE INTO PLACE. ENGAGE REAR LEG ONTO ANCHOR CLIP BY PRESSING DOWNWARD UNTIL SNAP LOCK OCCURS.

NOTE: REMOVE PROTECTIVE PLASTIC FILM IMMEDIATELY.



800-356-3521 www.soprema.us


310 Quadral Dr. Wadsworth, OH 44281 f: 330-334-6257

DATE: 02/19/25 DRN BY: MLM CKD BY: MM

SHT.# 6 OF 8


CKD BY: MM

INSTALLATION INSTRUCTIONS




INSTALLATION INSTRUCTIONS

#### SOPRA-TITE GOLD RADIUS COPING INSTRUCTIONS




STEP 1 - ANCHOR CLIPS

NOTE: RADIUS WILL HAVE DOUBLE SPRING ANCHOR CLIPS. ANCHOR CLIPS WIDTH WILL BE DETERMINED BY RADIUS SIZE AND MATERIAL. LOCATE AND FASTEN ANCHOR CLIPS WITH PROVIDED FASTERNERS FOR SUBSTRATE. SEE PAGE 4, AND ANCHOR CLIP SPACING.




STEP 2 - SPLICE PLATES

NOTE: ANCHOR CLIPS WIDTH WILL BE DETERMINED BY RADIUS SIZE AND MATERIAL. ALL SPLICE PLATES ARE PROVIDED. REMOVE RELEASE PAPER LEFT TWO SEALANT STRIPS. INSERT SPLICE PLATE HALFWAY INTO THE RIGHT END OF RADIUS SECTION.



NOTE: 4'-0" O.C. SHOWN.

REMOVE RELEASE PAPER FROM RIGHT TWO FACTORY APPLIED SEALANT STRIPS ON THE SPLICE PLATE ON THE COPING SECTION. INSTALL RADIUS COPING SECTIONS FROM LEFT TO RIGHT. PLACE COPING INTO POSITION AND PRESS DOWNWARD UNTIL SNAP-LOCK OCCURS.



STEP 3 - COMPLETION

USING RADIUS SECTIONS TO COVER ALL EXPOSED CLIPS / SPLICES, CUT TO LENGTH AS NEEDED USING A FINE TOOTH HACKSAW, SNIPS, OR CUT-OFF WHEEL LEAVING A CLEAN EDGE. BE SURE TO LEAVE A 3/8" SPACE AT EACH JOINT.

NOTE: REMOVE PROTECTIVE FILM IMMEDIATELY.



800-356-3521 www.soprema.us

310 Quadral Dr. Wadsworth, OH 44281 f: 330-334-6257

DATE: 02/19/25 DRN BY: MLM

CKD BY: MM

SHT.#\_8\_ OF \_8\_