

FASCIA EXTENDER

LAP JOINT VERSION

INSTALLATION INSTRUCTIONS



- STEP (1)- CAREFULLY POSITION AND FASTEN CONTINUOUS CLEAT 12" (304.8 mm) O.C. AS SHOWN WITH APPROPRIATE FASTENERS. CLEAT SHALL BE INSTALLED TRUE AND LEVEL.
- STEP (2)- HOOK DRIP EDGE OF EACH FASCIA EXTENDER ONTO CONTINUOUS CLEAT AND FASTEN WITH APPROPRIATE FASTENERS AT 12" (304.8 mm) O.C.



TYPICAL INSTALLATION (Substrate may vary per job conditions.)

FASČIA **EXTENDER FASTENERS** (TYP.)

PROVIDED. FIELD CUT AS NECESSARY.

CAUTION: REMOVE PROTECTIVE FILM IMMEDIATELY AFTER INSTALLATION. INSTALLERS SHALL WEAR PROTECTIVE

EYEWEAR TO PREVENT INJURY.



800-356-3521 www.soprema.us

310 Quadral Dr. Wadsworth, OH 44281 f: 330-334-6257

DATE: 08/27/15 DRN BY: JJC

CKD BY: SAK

SHT.#

DWG# 33114-22568

CONTINUOUS CLEAT

OF