

CREATIVE DESIGN REVEAL COPING

3'-0" O.C.

INSTALLATION INSTRUCTIONS


IMPORTANT: Prior to installation, read instructions carefully.

NOTE: Position roof membrane on top of the wall covering the treated wood nailer(s) or substrate completely. Allow 1/2" minimum excess membrane beyond nailer where applicable.
NRCA requirement. Membrane not shown for clarity.


CAUTION: INSTALL MITERS FIRST!

INSTALLATION NOTES:

- 1) Installing contractor shall check as-built conditions, including nailer attachment, and verify the manufacturer's coping details for accuracy to fit the wall assembly prior to fabrication.
- 2) Fasteners must be corrosion resistant and rated for a minimum 250# pullout force for the substrate that is being used.





TYPICAL COPING INSTALLATION OUTSIDE FACE HEIGHT LESS THAN 9" DETAIL A




NOTE: THE FOLLOWING INSTALLATION INSTRUCTIONS REFLECT OUTSIDE FACE HEIGHTS OF LESS THAN 9".

TYPICAL COPING INSTALLATION OUTSIDE FACE HEIGHT 9" AND ABOVE DETAIL B



STEP 1 - CORNER SUPPORT CLIPS

LOCATE AND FASTEN ONE 5 1/2" WIDE GALVANIZED CORNER SUPPORT CLIP TO THE WALL AS SHOWN.



STEP 2 - MITER SPLICE PLATES & ANCHOR CLIPS

POSITION THE SPLICE PLATE IN THE CENTER OF THE ANCHOR CLIP. INSTALL THE SPLICE PLATE AND ANCHOR CLIP ASSEMBLY INTO EACH END OF THE CORNER AS SHOWN



Phone: 800-558-2162
Fax: 800-373-9156
www.metalera.com

DATE: 07/28/22
DRN BY: MLM
CKD BY: MM

SHT.# 1 OF 3


DWG# 11111-39167

A

CREATIVE DESIGN REVEAL COPING

3'-0" O.C.

INSTALLATION INSTRUCTIONS




STEP 3 - MITER

HOOK MITER ONTO CORNER CLIP AND ROTATE INTO PLACE. SECURE AT THE EXPOSED EDGE OF THE ANCHOR CLIPS AS PER DETAIL A.


LEFT ENDCAP SHOWN

OUTSIDE FACE




STEP 4 - ENDCAP ANCHOR CLIPS

LOCATE AND FASTEN GALVANIZED ANCHOR CLIPS TO WALL WITH PROVIDED FASTENERS FOR SUBSTRATE (SEE DETAIL A).




STEP 5 - ENDCAP SPLICE PLATES

REMOVE RELEASE PAPER FROM TOP OF FACTORY APPLIED SEALANT STRIPS. PLACE SPLICE PLATE ONTO SECOND ANCHOR CLIP AS SHOWN.




STEP 6 - ENDCAP

HOOK OUTSIDE FACE OF ENDCAP OVER THE ANCHOR CLIPS AND ROTATE INTO PLACE. ENGAGE REAR LEG ONTO ANCHOR CLIPS BY PRESSING DOWNWARD UNTIL SNAP LOCK OCCURS.




STEP 7 - ANCHOR CLIPS

LOCATE AND FASTEN GALVANIZED ANCHOR CLIPS TO WALL AT 3'-0" CENTERS WITH PROVIDED FASTENERS FOR SUBSTRATE (SEE DETAIL A).




STEP 8 - SPLICE PLATES

PLACE SPLICE PLATE ONTO ANCHOR CLIPS AT SPLICE JOINTS, 12'-0" O.C. NOTE: REMOVE RELEASE PAPER FROM SEALANT STRIPS.



STEP 9 - COPING

HOOK OUTSIDE FACE OF COPING OVER THE ANCHOR CLIPS AND ROTATE INTO PLACE. ENGAGE REAR LEG ONTO ANCHOR CLIPS BY PRESSING DOWNWARD UNTIL SNAP LOCK OCCURS.



STEP 10 - COMPLETION

CONTINUE INSTALLING COPING WITH A 3/8" SPACE AT SPLICE JOINTS TO ALLOW FOR THERMAL EXPANSION. FIELD CUT WHERE NECESSARY USING FINE TOOTH HACKSAW OR SNIPS. NOTE: REMOVE PROTECTIVE FILM IMMEDIATELY.



Phone: 800-558-2162
Fax: 800-373-9156
www.metalera.com

DATE: 07/28/22
DRN BY: MLM
CKD BY: MM

SHT.# 2 OF 3

DWG# 11111-39167

A


CREATIVE DESIGN REVEAL COPING

3'-0" O.C.

INSTALLATION INSTRUCTIONS

TYPICAL COPING INSTALLATION OUTSIDE FACE HEIGHT LESS THAN 9"

DETAIL A



TYPICAL COPING INSTALLATION OUTSIDE FACE HEIGHT 9" AND ABOVE

DETAIL B

