


# RADIUS COPING


## MEASUREMENT INSTRUCTIONS

1. Using the 36" straight edge provided, set it against the concave face of the parapet wall (as illustrated) typically 2-3 inches down from the top of the wall.
  2. Using the 12" rule provided, measure the distance (rise) from the edge of the yardstick at the 18" mark straight in to the face of the parapet.
  3. Repeat steps 1 and 2 in several more areas along the arch. Record these measurements in the boxes provided. We will calculate the radius from these measurements.
- NOTE!** If the measured rise dimensions vary by  $\frac{1}{2}$ " or over, contact Engineering Dept. at 800-558-2162 - Ext. 403 for further instructions
4. Fill in the general information below and fax this sheet back to 800-373-9156.

CONVEX RADIUS  
CONDITION  
PLAN VIEW



CONCAVE RADIUS  
CONDITION  
PLAN VIEW



PROJECT:	Corporate Offices, Manufacturing 1600 Airport Road; Waukesha, WI 53188 Phone: 800-558-2162 Fax: 800-373-9156 www.metalera.com
ARCHITECT:	
ROOFING CONTRACTOR:	
REPRESENTATIVE/DISTRIBUTOR:	



DATE: 04/02/12	SHT.# ____ OF ____	
DRN BY: JJC	DWG# 11511-1498	<b>B</b>
CKD BY: SAK		