


# ARCH TO STRAIGHT COPING MITER

## ANGLE MEASUREMENT INSTRUCTIONS

1. Cut a straightedge 16" long.
2. Lay the straight edge against the top of the arched portion of the miter area. Align the straightedge at the corner of the miter area and at the top edge of the arch (as illustrated).
3. Measure the angle as shown. Record this measurement in the box provided.
4. Fill in the general information below and fax this sheet to Metal-Era.

### RIGHT HAND MITER SHOWN



### ELEVATION VIEW FROM ROOF SIDE

PROJECT:	Corporate Offices, Manufacturing 1600 Airport Road; Waukesha, WI 53188 Phone: 800-558-2162 Fax: 800-373-9156 www.metalera.com
ARCHITECT:	
ROOFING CONTRACTOR:	
REPRESENTATIVE/DISTRIBUTOR:	



DATE: 09/21/05	SHT.# _____ OF _____
DRN BY: JJC	DWG# 11511-1589
CKD BY: SAK	