


# NON 90° ANGLE FOR FASCIA

MEASUREMENT WORKSHEET FOR USE WITHOUT A PROTRACTOR



1. CIRCLE APPROPRIATE "ROOF SIDE" TO INDICATE OUTSIDE MITER OR INSIDE MITER. THIS DETAIL APPLIES FOR MITERS TIGHTER THEN 90° (ACUTE) OR WIDER THEN 90° (OBTUSE).
2. STARTING AT EITHER SIDE OF THE CORNER, MEASURE ALONG THE WALL EDGE A CONVENIENT DIMENSION, SUCH AS 24" OR 36", DEPENDING ON JOB SITE CONDITIONS. PLACE A MARK ON THE WALL AND RECORD MEASURED DIMENSION AS "DIM A" IN THE DRAWING ABOVE, REPEAT PROCEDURE FOR THE OPPOSITE WALL, AS SHOWN ABOVE.
3. MEASURE STRAIGHT ACROSS FROM MARK TO MARK, AS SHOWN, AND RECORD THE MEASURED DIMENSION AS "DIM B".
4. FAX THIS SHEET TO 800-373-9156 WITH ORDER.

PROJECT:	51 Lexington Street; Lewiston, ME 04240 CUSTOMER SERVICE: 800-223-8317 USA 800-445-1500 Canada TECHNICAL SERVICE: 800-445-1500 USA & Canada FAX: 207-784-0125 OTHER AREAS CALL: 207-784-0123
ARCHITECT:	
ROOFING CONTRACTOR:	
REPRESENTATIVE/DISTRIBUTOR:	



DATE: 09/15/08	SHT.# ___ OF ___
DRN BY: JJC	DWG# 16510-2319 <b>B</b>
CKD BY: SAK	