


1. Dow Membrane


Position Dow Roofing Membrane over the roof edge and down outside face of wall, covering treated wood nailer(s) completely, as shown in Standard Detail HT-130.

IMPORTANT! Outside edge of treated wood nailer(s) (minimum 2 x 4) shall be aligned flush with or extend slightly past outermost edge of wall.



2. Miter & Scupper Anchor Rail (Preparation)


Lay miters and spillout scuppers on deck with outside face down. Be sure aluminum anchor rail is clean and free of dirt or dust. Apply a heavy 3/8" (10 mm) bead of Dow All-Purpose Sealant to the right angle intersection of the deck flange and back of anchor rail as shown. Application of sealant is required along the full length of each miter anchor rail.



3. Anchor Rail Splice Plates

Apply Dow All-Purpose Sealant to each splice plate as shown and described in STEP 2.


CAUTION! Installers shall wear protective eyewear to prevent injury. Do not over-drive fasteners, as stripping can occur at high driver torque. Recommended Driving Tool : 600 - 800 rpm electric drill equipped with depth-sensing nosepiece to prevent over-driving and stripout. Do not use impact type tool.



4. Miter Bar Installation


Fold roofing membrane at corners and install miters using the 2" (41 mm) Hex Head Stainless Steel fasteners and Driver Bit furnished by Dow Roofing Systems. Fasten anchor rail miters to nailer with one splice plate under each end of miters. The anchor bar splice plate must be snug to ends of anchor rail. Next locate and install spillouts and scuppers with sealant, 2" fasteners and anchor bar splice plates.





5. Anchor Rail (Installation)


Position 12'-0" (3.65 m) sections of anchor rail with applied Dow All-Purpose Sealant as shown in steps 2 & 3 overlapping anchor bar splice plate. Allow 1/2" (13 mm) space between anchor rails. Install anchor bar splice plate at other end of 12'-0" (3.65 m) rail. Fasten anchor rail 12" (305 mm) o.c. through slots using 2" (51 mm) stainless steel fasteners. Field cut sections as necessary.



6. Fascia Miters Covers

Install 2-piece "snap-on" fascia miter covers first by snapping on fascia corner cover with 90° (degree) tab, followed by corner cover without the tab. Simply position the cover atop rail with palm of hand apply slight pressure downward until engaged to anchor rail.

IMPORTANT! Be sure to remove protective plastic film prior to installing each fascia section.



7. Fascia Panels

Position 12'-0" (3.65 m) fascia panels on top of anchor rail and overlap preceeding panel approximately 1" (25 mm) at notches provided. Fascia covers shall be installed from right to left as seen from rooftop. With fascia panels in correct position atop anchor rail, simply snap each section onto anchor rail by applying downward pressure with palm of the hand until the fascia cover is fully engaged along the entire length. Continue to install fascia covers, field cutting where

